

BATCH

LESSON

DATE

B107 AWS DevOps

Network

29.12.2022

SUBJECT: Troubleshooting

ZOOM GİRİŞLERİNİZİ LÜTFEN **LMS** SİSTEMİ ÜZERİNDEN YAPINIZ






















Previous Session

Subnetting CIDR



Contents

- Troubleshooting
- Hands-on Lab





What is a Network?



A computer network is a group of computers that use a set of common communication protocols over digital inter-connections for the purpose of sharing resources located on or provided by the network nodes.



Types of Networks

Georaphical

- NANO
- BAN
- PAN
- LAN
- CAN
- MAN
- WAN

Network Architecture

- Client –Server
- P2P

Topological

- Ring
- Star
- Mesh
- Bus
- Line

Transferring Mediums

- Cable
- Wireless
 - RF
 - Laser
 - Microwaves



OSI Reference Model

ENCAPSULATION

•SMTP **APPLICATION** •FTP •TELNET FORMAT DATA **PRESENTATION** ENCRYPTION •START **SESSION** •STOP •TCP **TRANSPORT** •UDP PORT NUMBERS • IP ADDRESS **NETWORK** •ROUTERS MAC ADDRESS DATALINK •SWITCHES •CABLE **PHYSICAL** •NIC •HUBS

CAPSULATION



Transmission Media

- Kablolu
 - Koaksiyel
 - Twisted pair(Burgulu Çift)
 - Fiber
- Kablosuz
 - Laser (WLAN)
 - Infrared (Bluetooth v.b)
 - Radyo Frekans (WLAN, Uydu Haberleşmesi)


01 01

Network Devices

- Network Interface Card (NIC)
- **♦**Hub
- Bridge
- Switch
- **❖**Router
- Firewall
- *****DNS
- *****DHCP
- Other specialized devices




Data Transmission





MAC Adres


- MAC adres dağıtımları IEEE tarafından yönetilir.
- □ MAC, 48 bit'lik bir adres olduğundan dolayı 2⁴⁸ = 281,474,976,710,656 değişik ağ kartını tanımlamak için kullanılabilir. MAC adresi (Fiziksel adres, Donanım adresi), ağ donanımının tanımlanmasını sağlar. MAC adresi, bilgisayarın ethernet
 - kartına üretici tarafından kodlanan bir bilgidir.
- □ Üreticiler MAC adres aralıklarını satın alırlar.
 - Aynı ağ içerisinde birbirine fiziksel olarak bağlı birimler arasında çerçeve transferinde kullanılır.





IP Adres

- ☐ IP adres:
 - Network Layer Address
 - Data Packet Segment Datagram
 - □ 32-bit _____ 17.172.224.47 (IPv.4)





SubnetMask

IP address 192.168.0.96 and Mask 255.255.255.0





Figure 3.1 IP address and mask in binary, showing network and host fields.



IP Classification





IP Classification

Class	Leading bits	Size of network number bit field	Size of rest bit field	Number of networks	Addresses per network	Total addresses in class	Start address	End address
Class A	0	8	24	128 (2 ⁷)	16,777,216 (2 ²⁴)	2,147,483,648 (2 ³¹)	0.0.0.0	127.255.255.255
Class B	10	16	16	16,384 (2 ¹⁴)	65,536 (2 ¹⁶)	1,073,741,824 (2 ³⁰)	128.0.0.0	191.255.255.255
Class C	110	24	8	2,097,152 (2 ²¹)	256 (2 ⁸)	536,870,912 (2 ²⁹)	192.0.0.0	223.255.255.255
Class D (multicast)	1110	not defined	not defined	not defined	not defined	268,435,456 (2 ²⁸)	224.0.0.0	239.255.255.255
Class E (reserved)	1111	not defined	not defined	not defined	not defined	268,435,456 (2 ²⁸)	240.0.0.0	255.255.255.255



Private Networks

Public and Private IP Addresses

- No two machines that connect to a public network can have the same IP address because public IP addresses are global and standardized.
- However, private networks that are not connected to the Internet may use any host addresses, as long as each host within the private network is unique.
- RFC 1918 sets aside three blocks of IP addresses for private, internal
 use.
- Connecting a network using private addresses to the Internet requires translation of the private addresses to public addresses using Network Address Translation (NAT).

Class	RFC 1918 internal address range
A	10.0.0.0 to 10.255.255.255
В	172.16.0.0 to 172.31.255.255
С	192.168.0.0 to 192.168.255.255



Case 1


Dynamic Addresses	3		
Secure Addresses (I		ount:	0
Static Addresses (Us			0
System Self Address		Pad	1
Total Mac addresses		5	9400
Non-static Address	Γable:		questions, co
	Address Time	MAIN	Destination
Destination Address	Address Type	ALMIA	Destination
		1	FastEthernet0/1
Destination Address 0010.0de0.e289 0010.7b00.1540	Dynamic Dynamic	1 2	

Switch-1 needs to send data to a host with a MAC address of 00b0.d056.efa4. What will Switch-1 do with this data?

- A. Switch-1 will drop the data because it does not have an entry for that MAC address.
- B. Switch-1 will flood the data out all of its ports except the port from which the data originated.
- C. Switch-1 will send an ARP request out all its ports except the port from which the data originated.
- D. Switch-1 will forward the data to its default gateway.




Case 2




PC1 Can't Access Camera Server. Why?



Case 3



PC3 and PC4 take APİPA IP. WHY?



Do you have any questions?

Send it to us! We hope you learned something new.